

# SEFAR® PCF

The pre-coated screen printing mesh – expose, develop, dry – print



swiss  
mesh  
technology



**S E F A R**  
■ ■ ■ ■

# SEFAR® PCF

The pre-coated screen printing mesh – expose, develop, dry – print

SEFAR® PCF, ready-made print forms in constant top quality. SEFAR® PCF is the innovative, unique pre-coated screen printing mesh for industrial screen printing and ensures superior print quality and efficiency. This innovative screen printing breakthrough is clean, space saving and environmental friendly.

Product features	Screen / stencil maker benefit	Printer benefit
<p><b>Elimination of preparation steps in combination with maximum process reliability and coating quality</b></p>	<ul style="list-style-type: none"> <li>▪ Eliminates the purchase of emulsion and complex stencil making process</li> <li>▪ Reduced handling time</li> <li>▪ Optimal stencil quality with minimum effort</li> <li>▪ The tension drop between the stretching process and printing is low, balanced and stable for subsequent print runs</li> </ul>	<ul style="list-style-type: none"> <li>▪ Print on demand and minimal machine downtime when changing the stencil</li> <li>▪ Very accurate reproduction of tonal values and registration accuracy</li> <li>▪ First-class stencil quality and printing results</li> <li>▪ Very good ability to reproduce fine detail even on large print runs</li> <li>▪ Uncompromised edge definition</li> <li>▪ Longest stencil life</li> <li>▪ Elimination of cleaning, stripping and ghost imaging removal</li> <li>▪ Reduction of bad copies</li> </ul>
<p><b>Unsurpassed UV-A light undercutting protection</b></p>	<ul style="list-style-type: none"> <li>▪ Absorption range adapted to the UV-A radiation spectrum</li> <li>▪ Sharp-edged reproduction of the artwork on the stencil</li> <li>▪ Finest detail reproduction in stencil</li> <li>▪ Wide exposure tolerance</li> </ul>	<ul style="list-style-type: none"> <li>▪ Sefar Yellow supports the printing of demanding tasks in which high resolution detail are essential</li> <li>▪ High reproducibility of the stencil even halftones and half-tone gradients</li> <li>▪ Best edge definition in print</li> </ul>
<p><b>Standard range</b></p>	<ul style="list-style-type: none"> <li>▪ Optimization of storage management</li> <li>▪ High reliability ensures continuous production</li> </ul>	<ul style="list-style-type: none"> <li>▪ Ensured continuous delivery of stencils</li> <li>▪ High quality standard range</li> <li>▪ No surprises in press</li> </ul>
<p><b>Environmentally friendly</b></p>	<ul style="list-style-type: none"> <li>▪ No storage of emulsions</li> <li>▪ Reduced use of chemicals in the stencil-making process</li> <li>▪ No more degreaser, wetting agent, stencil and ghost remover are required</li> </ul>	<ul style="list-style-type: none"> <li>▪ Reduction of the cleaning cycles, easy disposal</li> <li>▪ Reduced storage of chemicals</li> <li>▪ Increased operational safety, since no chemical additives</li> </ul>
<p><b>Developed and manufactured to meet the highest industry standards</b></p>	<ul style="list-style-type: none"> <li>▪ Process stability through consistent quality control</li> <li>▪ Quality you can count on</li> </ul>	<ul style="list-style-type: none"> <li>▪ High quality printing results</li> <li>▪ Process reliability thanks to the best stencil quality</li> <li>▪ Predictable results, no surprises on press</li> </ul>


# SEFAR® PCF

The pre-coated screen printing mesh – expose, develop, dry – print


## Expose, develop, dry – print

SEFAR® PCF combines the highest quality, process reliability, reproducibility, and lean stencil manufacture. Cleaning, coating and decoating processes are eliminated. This simplifies the order planning and speeds up the processing. Procurement and inventory management of chemicals are eliminated. No longer investment in cleaning and coating equipment and their maintenance and cleaning effort. Less waste of material occurs – buy what you pay for, don't drain unused. Result: Print on demand!


## Coating/emulsion types



Sharp edged, rectangular printing channel with SEFAR® PCF FC 180/460-27Y, 3 µm EOM



SEFAR® PET 1500 180/460-27Y, 15 µm capillary film with 7 µm EOM



SEFAR® PET 1500 180/460-27Y, direct emulsion with 4 µm EOM

## Applications

Expand your options with SEFAR® PCF for screen printing on plastic containers, labels, glass ware, optical discs and many other challenging print substrates.



Outstanding printing quality of fine halftones on plastic tubes printed with SEFAR® PCF FC 180/460-27Y



Fine detailed art work on CD printed with SEFAR® PCF CD 150/380-31Y




Sharp edged and well readable text on labels printed with SEFAR® PCF FC 165/420-27Y



High dense sharp edged letters on perfume flacon with SEFAR® PCF FC 120/305-34Y

## Mesh assortment

The SEFAR® PCF range is designed to the requirements of individual applications regarding emulsion, mesh types and widths. Choose the ideal screen printing stencil system for your projects from our SEFAR® PCF product portfolio. For specific advice on your application please contact your local Sefar sales representative.



## Sefar worldwide

Sefar is the leading manufacturer of precision fabrics from monofilaments for the screen printing and filtration market. Sefar products are used in a wide variety of industries, reaching from electronics, graphics, medical, automotive, food and pharmaceutical applications to aerospace, mining & refining and architecture. With its profound understanding of the applications Sefar helps its customers to achieve optimum results in their industrial processes. Subsidiaries and fabrications centers around the world provide local technical service for the broad range of solutions offered by Sefar.

### Headquarters

**Sefar AG**  
Hinterbissastrasse 12  
9410 Heiden – Switzerland  
Phone +41 71 898 57 00  
Fax +41 71 898 57 21  
printing@sefar.com  
[www.sefar.com](http://www.sefar.com)

### Subsidiaries Americas

**USA** – Buffalo  
Phone +1 800 995 0531  
sales@sefar.us

**Mexico** – Cuautitlan Izcalli  
Phone +52 55 5394 8689  
info.mexico@sefar.com

**Brazil** – São Bernardo do Campo  
Phone +55 11 4390 6300  
printing@sefar.com

### Subsidiaries Asia

**Singapore**  
Phone +65 6299 9092  
info.sg@sefar.com

**China** – Shenzhen  
Phone +86 755 2382 0322  
printing@sefar.com

**China** – Suzhou  
Phone +86 512 6283 6383  
printing@sefar.com

**Hong Kong** – Kwai Fong N.T.  
Phone +852 2650 0581  
printing@sefar.com

**India** – Thane  
Phone +91 2522 2940 34/35/36  
printing@sefar.com

### Subsidiaries Europe

**Spain** – Cardedeu  
Phone +34 93 844 47 10  
printing@sefar.com

Your Sefar trading partner:



Our most current general sales conditions shall apply.  
Please consult the most current local product data sheet prior to any use.

**S E F A R**  
■ ■ ■ ■