

Leaf Filter

Sefar is specialized in producing ready-to-use covers, integrating innovative solutions to increase lifetime and efficiency for new and older machines.



Product Features

Sefar filter solutions for Leaf Filters

For several decades, Sefar is the leading supplier of covers, bags and candles for all types of horizontal and vertical pressure and vacuum leaf filters, such as Cricket, Diastar, Kelly, Tamaris, Miningtech Moore, Outotec and others. Leaf filter bags are developed in close cooperation with leading equipment manufacturers as well as directly with end users, paying attention to the specific requirements of the filter equipment and separation application.

Experience

Sefar proposes a large range of solutions to answer all the customer's requirements, such as:

- Chemical, mechanical and abrasive resistance
- Dimensional stability
- Resistance of the media against clogging, blinding or scaling, coupled with a high regeneration capacity*
 (*capacity of the woven fabric to recover the original permeability after a washing)
- High strength resistance against tearing
- For the food industry : FDA, EU 10/2011, EC 1935/2004, EC 2023/2006 compliance

DOWNLOADS

Brochure: Process Filtration (PDF 8341 kb)

Sefar BDH Inc.

200 rue Clement Gilbert
 Saguenay QC, G7H 5B1 – Canada

Phone +1 418 690 0888
 Fax +1 418 690 9499

info.bdh@sefar.com

[Go to product page](#)

- NEW: Filter media with unique anti-scaling properties, exclusively available through Sefar, called x-Scale, which delay the scaling in applications such as alumina pregnant liquor clarification (security filtration) with the target to keep the flow rate stable for a longer period of time and reduce the maintenance cycles

Knowledge

For years, Sefar has continuously developed woven media with consideration for the specific needs of pressure leaf filters.

- Resistance to temperature > 100°C with the minimum of shrinkage
- Strong resistance for the maximum lifetime
- Productivity given by an optimum flow rate
- Cake moisture (cake dryness, moisture content)
- Cake thickness
- Filtration efficiency (filtrate clarity, solids in filtrate, particle retention, solids in suspension)
- Cake release (cake discharge)
- Cake washing efficiency

Solutions

Sefar proposes solutions to cope with all customer frame or tube design, with ready-made and adapted filter housings, which match perfectly to any form of the support (from round to square) but which can, moreover:

- prevent or delay some damage induced by cake recovery

Sefar BDH Inc.

200 rue Clement Gilbert
Saguenay QC, G7H 5B1 – Canada

Phone +1 418 690 0888
Fax +1 418 690 9499

info.bdh@sefar.com

[Go to product page](#)

- prevent or delay damage induced by frames in poor condition
- ensure the best seal possible between cover and support

Innovation

To achieve this target, Sefar can offer standard and innovative solutions.

- Welding assembly is available to avoid any loss of product through the holes created during sewing
- Reinforcement with high resistance against abrasion and compatible with difficult chemical environments and applied to the sensitive areas to protect the fabric, thereby improving lifetime
- NEW: Special top for Diastar bags, to avoid any scaling on top area and facilitate removal and consequently help to keep the material in good conditions.

Fabrication solutions

Finished bags and covers for leaf filters from Sefar are equipped with options that significantly simplify the installation of the products. Most of our products have welded seams, which ensure minimal product loss since there are no stitching holes. A newly developed closing system (patent pending), for the mineral industry especially, facilitates the installation of leaf filters which reduces operational expenses and the risk of leakages.

Fabricated leaf filter bags



Sefar BDH Inc.

200 rue Clement Gilbert
Saguenay QC, G7H 5B1 – Canada

Phone +1 418 690 0888
Fax +1 418 690 9499

info.bdh@sefar.com

[Go to product page](#)